



PRESSURE PROTECTION VALVES

Pressure Protection Valves



INFORMATION:

- Commonly used to protect air brake reservoirs from being depleted by the failure of other air accessory items
- Valves open at a factory set psi & allow air to flow through to the Outlet Port
- Valves close at the nominal psi indicated below

PART NUMBER	PORT SIZES (NPT)		NOMINAL CLOSING PRESSURE
	Inlet	Outlet	
110258	3/8"	3/8"	90 psi
110657	3/8"	3/8"	70 psi