



FIGURE 3

110595

RELEASE OF CONTROL PORT AIR PRESSURE MOVES THE DIAPHRAGM ASSEMBLY AND ACTUATOR, ALLOWING DELIVERED AIR TO FLOW FROM ALL PORTS AND EXIT THROUGH THE CONTROL PORT. THIS ALLOWS THE RELEASE OF THE AIR RIDE BAGS.

VALVE SHOWN IN RIDE BAG RELEASE POSITION