



FIGURE 1
2000D-1/2

SUPPLY AIR FROM TRAILER RESERVOIR IS INTRODUCED INTO THE VALVE THRU THE INLET PORT.

VALVE SHOWN IN INITIAL OR RELEASE POSITION