

## FIGURE 2 2000D-1/2

AIR FLOWS INTO INLET PORT PUSHING DIAPHRAGM DOWN CLOSING EXHAUST PORT. DIAPHRAGM ALSO DEFLECTS, ALLOWING AIR TO FLOW OUT BOTH DUTLET PORTS.

VALVE SHOWN IN A DELIVERY APPLICATION